




BINO




1.




TYP 04



TYP 05 / 06




TYP 07 / 08




TYP 09

2.




TYP 04

TYP 05 / 06








TYP 07 / 08



TYP 09

3.









C33

X10




N2

5x70




Ø10x50




4.



Deaktivace/Deaktivácia/Deactivation/Deaktivierung/Désactivation/Desactivación/Deactivering/Disattivazione/Dezactivare/Hatástalanítás



Aktivace/Aktivácia/Activation/Aktivierung/Activation/Activación/Activering/Attivazione/Activare/Aktiválás



5.

